


Niagara Interface to NOVUS Access Security Systems

The Niagara Framework™ to NOVUS Access SW Interface is a Partner Application developed by Tridium and NOVUS Technology, Inc. that links the Niagara Framework and the NOVUS Access Control System. This interface is compatible with the Vykon Building Automation Suite and Building Automation Applications that are based on the Niagara Framework. The NOVUS Access SW integration software provides the interface between the NOVUS Access SW application and the Niagara Framework driver that resides in each Niagara station.



Applications

The NOVUS Access SW Interface provides the ability for the Niagara Framework to interface with a NOVUS card access system. The interface allows Niagara Framework users to monitor access control functions, and integrate card access with HVAC, lighting and other facilities operations. A standard browser interface can be used to configure cards, monitor user activity, and integrate card access data to tenant billing and other advanced facilities applications.

NOVUS/Niagara Interface


Product Data Sheet



Features

- Provides a card access application integrated with the Vykon software suite
- Display door access and building automation information on the same web page from the Niagara Browser User Interface
- NOVUS Access SW can run on the server with Web Supervisor
- The NOVUS driver resides in each JACE requiring an interface to the NOVUS Access SW database
- Web access to the NOVUS Access SW Interface is provided through the Web Supervisor or JACE with UI services and a browser
- Provide access to individual reports for each door from the browser interface
- Operate lighting and HVAC equipment automatically as a result of access granted to the associated space

Niagara Interface to Novus Security Systems



Platform Requirements

- The NOVUS driver must be installed on all JACE stations monitoring data from the NOVUS Access SW, and the client quantity must match or exceed the number of access doors
- NOVUS Access SW must be installed in a separate server or the Web Supervisor server.

Ordering Information

- **DRV-NOVUS** NOVUS Access SW Security System driver including two door client license.
- **DRV-NOVUS-DR** NOVUS Access SW client license for additional doors. One client license required for each access door to be monitored by the JACE.

For more information on NOVUS Technology, Inc. and the NOVUS Access SW applications, please refer to www.novus-security.com



www.tridium.com

North America
3951 Westerre Pkwy, Suite 350
Richmond, VA 23233-1313
USA
1.804.747.4771 Phone
1.804.747.5204 Fax

Europe
100 Lodge Lane6 Temasek Boulevard
Little Chalfont, Buckinghamshire HP8 4AH
UK
44 (0) 1494.766377 Phone
44 (0) 1494.766311 Fax

Asia Pacific
#16-03 Suntec Tower 4, 038986
Singapore
+65.6.887.5154 Phone
+65.6.887.5342 Fax